

Read Me First

Included in this package should be (4) items:

- 1) Shower Manager unit (does **not** include showerhead)
- 2) Round Magnet
- 3) Installation and Programming Inst. (other side)
- 4) Read Me First information sheet



Setup of Unit

When installing the unit, **DO NOT use plumbers putty or piping compound.** Particles of this material will clog the inlet ports. The Shower Manager threads and washers should provide an adequate seal. If additional sealing is needed, **use only Teflon tape. (not provided)**

Which Showerhead to use?

Any standard showerhead purchased since 1992 that complies with gov't guidelines of not delivering more than 2.5 GPM should work fine. If you have an older showerhead (pre-1992) that provides more than 2.5 GPM, you may notice less water pressure.

Showerheads **not** recommended when using the Shower Manager:

- Massaging showerhead
- Pulsating showerhead
- Showerhead combing oxygen with water
- Showerhead with On/Off valve
- Ultra low-flow showerheads

While these type showerheads **may** work, they may also interfere with the performance of the Shower Manager.

Understanding How the Time Settings Work

The Shower Manager has three full-flow time settings: 5, 8 or 11 minutes. The Installation and Programming Sheet explains how to change these settings. When the full-flow time expires and the unit advances into restricted mode, the unit goes into a 5-minute reset interval during which time only a restricted flow of water is permitted. (This reset interval prevents the shower taker from extending their shower)

While in full-flow the water can be turned off to conserve water (often referred to as Navy shower) while lathering up. However, if the bather finishes showering before their full-flow time is up, the reset interval does not begin until their full-flow time expires.

To avoid this unused full-flow time from extending the reset interval, set the full-flow time that will most often be used. Educating bathers on the operation of the Shower Manager is a must!

The Shower Manager **does not fully shut off water flow.** In restricted mode the water flow is cut by 2/3 of full flow. Your main shower tap still controls the On/Off function and the mixture of Hot / Cold water. As a helpful hint, **if you are trying to cut back on bathers taking 20 to 30 minutes showers, we recommend starting with the 11 minute full-flow setting.**

See Installation and Programming Instructions on reverse side.

For Troubleshooting and Frequently Asked Questions, go to:

www.ShowerManager.com

Shower Manager 2942 S. Trenton St. Denver, CO 80231

info@ShowerManager.com

1/1/09

Warranty: The Shower Manager is backed by a Full Satisfaction 90-Day Warranty. If you are not fully satisfied with your Shower Manager, please return it within 90 days of date of order for a full refund. Full Refund includes purchase price plus initial cost of shipping. Return shipping is not included in the warranty.